Index

Valve Adapters

D02 to D03 Valve Adapter - AB Oriented, Short & Tall Styles 3.02.01
D03 to D02 Valve Adapter - AB Oriented 3.02.01
D03 to D05 Valve Adapter - AB or BA Oriented, Short Style 3.02.02
D03 to D05 Valve Adapter - AB or BA Oriented, Tall Style 3.02.02
D05 to D03 Valve Adapter - AB Oriented 3.03.01
D05H/HE to D03 Valve Adapter - AB Oriented 3.03.01
D05 to D03 Valve Adapter - BA Oriented 3.03.02
D05H/HE to D03 Valve Adapter - BA Oriented 3.03.02
D05/D05H/D05HE to D05H Valve Adapter with External Pilots 3.03.03
D05/D05H/D05HE to D05HE Valve Adapter with External Pilots 3.03.03
D05H to D05HE Valve Adapter - AB Oriented 3.03.04
D05HE to D05H Valve Adapter - AB Oriented 3.03.04
D05 to D05"L" - Valve Adapter with External Drain 3.03.05
D05H/HE to D05"L" Valve Adapter with External Drain 3.03.05
D07 to D03 Valve Adapter - AB Oriented 3.04.01
D07 to D05 Valve Adapter - AB Oriented 3.04.01
D07 to D05H Valve Adapter - AB Oriented 3.04.02
D07 to D05HE Valve Adapter - AB Oriented 3.04.02
D08 to D03 Valve Adapter - AB Oriented 3.05.01
D08 to D05 Valve Adapter - AB Oriented 3.05.01
D08 to D05H Valve Adapter - AB Oriented 3.05.02
D08 to D05HE Valve Adapter - AB Oriented 3.05.02
D08 to D07 Valve Adapter - AB Oriented 3.05.03
D06 to D05 Valve Adapter - AB Oriented 3.05.03
D10 to D07 Valve Adapter - AB Oriented 3.06.01
D10 to D08 Valve Adapter - AB Oriented 3.06.01
Obsolete Valve Adapters ..... Consult Factory
Rotators, Spacers, Specials, Servo/Servo Valve Adapters ..... Consult Factory
Servo/Directional, Directional/Servo Valve Adapters ..... Consult Factory

WE RESERVE THE RIGHT TO DISCONTINUE MODELS, OR CHANGE SPECIFICATIONS WITHOUT NOTICE OR INCURRING OBLIGATION